



po box 1856 • media, pa 19063

tel • 484.620.2976 fax • 610.494.1870

email • info@nightorbs.com • www.nightorbs.com

## Lamp Replacement

NightOrbs™ use state-of-the-art Xelogen lamps which have an average life span of 20,000 hours, depending on bulb wattage. To replace lamp:

- Remove the NightOrb™ by loosening the 5/64" set screw in part B of the base (use Allen wrench provided).
- Grasp and hold the base and the stem with one hand and with the other hand, turn the NightOrb™ counter-clockwise to the stem, to reveal Xelogen lamp.
- With NightOrb™ removed, replace the lamp and then reattach the NightOrb™.
- Hand-tighten so base fins between A and B line up. Important: Do NOT over tighten; this will make removal difficult at a future date.
- Tighten set screw.
- The NightOrb™ is now ready to be plugged back into service.

### **CAUTION:**

Do not get dirt in the base threads or gasket area of the NightOrb™.